Mason Competitive Cyber

Intro To CTF Forensics



What is Forensics



Forensics in the context of CTFs usually involves some thing to do with either recovering deleted files from an image file or fixing broken files to being able to find files hidden inside of the other

Types of files you might see



- There are many different types of files you might come across but here are some important ones and the tools/programs you should try first
 - o .img, .raw, .e01 These should be opened with autopsy, or FTK imager
 - dmp or other memory dumps you can use volatility
 - Pcap, cap uses wireshark usually

Methodology



- The first thing that I usually use is the **file** command in linux
 - This can be confused if the magic bytes are manipulated
 - The file extension means nothing
- Strings is useful for finding text in the file
 - You can also pipe strings into grep or awk
- Xxd or hexdump to look at the hex output to look for magic bytes

File Carving



- File inside files is a common theme in many ctfs
- There are several tools that can be used for file carving
 - Binwalk
 - Scalpel/foremost
 - You can also use DD for manual file carving
 - \$ dd if=./file_with_a_file_in_it.xxx of=./extracted_file.xxx bs=1 skip=1335205 count=40668937

Useful options for binwalk



- Binwalk -e [file.ext]
 - This will extract the files found the the file to your current directory
- Binwalk -dd='*.png' [file.ext]
 - This will extract all pngs from the file but you can use any extension

Images/Steg



- Exiftool
- NCL really likes digital invisible ink toolkit
- Analyze the header and contents with a hex editor
- Pngcheck can help check for corruption
- Zsteg can find hidden data
- Stegsolve can unhide flags easily

Audio Files



- Check file with binwalk
- Use audacity
- Check spectrograms
- Sonic visualizer is good for that

Volatility




- Used for memory dump analysis
- Basic commands
 - python vol.py -f %image_name% imageinfo
 - Gets the profile to continue working on the dump
 - o python vol.py -f %path_to_image% --profile=%profile_name% pstree
 - Shows all of the running processes



- Used for looking at pcaps
- Things to look for include insecure protocols like HTTP, FTP, Telnet
- Following http streams can help make things more visible
- You can export things from the packet analysis using export and then http
 objects or you can follow the tcp steam and then save it to your desktop







Wireshark · Follow TCP Stream (t	tcp.stream eq 2) · extracting-objects-from-pcap-example-05.pca	р (2
1Z@. This program cannot be run	n in DOS mode.	lL.l =
z[s[z[Rich~.z[[z[8[;.z[8[z[.q.[s.z[~.{[z[s[. 	
		P
	text	ACCOUNT OF THE PROPERTY OF THE
		hp
HZYhHjY. .HJ=.JJ. Ht0VjHt9V .VHH.^hH	CJJj Ht,.:.u.3W.yAu.+QRI	2
lient pkts, 529 server pkts, 0 turns.		
ntire conversation (672 kB)	Show and save data as ASCII	Stream 2
d:		Find <u>N</u> ext
Help	Filter Out This Stream Print Save as Bac	k <u>C</u> lose



Wireshark · Follow TCP Str	eam (tcp.stream eq 2) · ex	tracting-objects-from	-pcap-example-0	5.pcap	0 - 0
MZ This program cannot be					.!L.!
:~.z[~.z[~ [z[s[z[Rich~.z[PE L : ((.		S.,,
					P
@rdataf					
.N 					
H Z Y h H j . H J = J H t0Vj H ts . V H H.^h H.	YhHZ JCJJ 9VHt,.:.u	j .3W.yA.	C Arrays		hp
lient pkts, 529 server pkts, 0 turns.		30003 33473 44744 5474 5474 5474 5474 5474 5	UTF-8		
ntire conversation (672 kB)	•	Show and save data		St	ream 2
nd:			YAML		Find Next
Help	Filter Out Th	nis Stream Print	Save as	Back	Close



Wireshark · Follow TCP Stream (tcp.	stream eq 2) · extra	ting-objects-from-	-pcap-example-0	5.pcap	0 - 0
d5a90000300000004000000ffff					
000000000000000000000000000000000000000	000000000000000f	000000000e1fba	a0e00b409cd2	1b8014c	cd2154
869732070726f6772616d206361	6e6e6f74206265	2072756e20696	Se20444f5320	6d6f646	52e0d0
0a24000000000000003aef14087					
a5b38df9a5ba58e7a5ba371b15b					
7a5b73dca45b7f8e7a5b5269636			TO CONTROL THE TAXABLE PARTY OF THE PARTY.	and the second second	
00000504500004c0104003a28fa				A CONTRACTOR OF THE PARTY OF	Production and Production
000000e8e107000010000000e00					
000000000a00a00000400000000					
1000000000000000000000000d4d					
00000000000500a00444c000000					
0000000000f8c80900400000000					
000000000000000000000000000000000000000					
000000000000000000000000000000000000000					AND PRODUCTION SHOWS AND ADDRESS.
000000000000000000000400000					
0000000000000000000000040000					
000000000000000000000000000000000000000					
000000000000000000000000000000000000000					
000000000000000000000000000000000000000					
000000000000000000000000000000000000000					A CONTRACTOR OF THE PARTY OF TH
000000000000000000000000000000000000000	0000000000000000	000000000000000	0000000000000	000000	000000
lient pkts, 415 server pkts, 0 turns.			N		
ntire conversation (672 kB)	▼ 9	how and save data	as Raw	Str	eam 2
d:					Find <u>N</u> ext
Help	Filter Out This S	Stream Print	Save as	Back	Close



```
-(chris⊕kali)-[~]
sudo autopsy
[sudo] password for chris:
                      Autopsy Forensic Browser
                  http://www.sleuthkit.org/autopsy/
                             ver 2.24
Evidence Locker: /var/lib/autopsy
Start Time: Wed Apr 13 00:50:28 2022
Remote Host: localhost
Local Port: 9999
Open an HTML browser on the remote host and paste this URL in it:
    http://localhost:9999/autopsy
Keep this process running and use <ctrl-c> to exit
```



WARNING: Your browser currently has Java Script enabled. You do not need Java Script to use Autopsy and it is recommended that it be turned off for security reasons. **Autopsy Forensic Browser 2.24** http://www.sleuthkit.org/autopsy/ OPEN CASE NEW CASE HELP



Case: example1

ADD A NEW HOST

numbe	t Name: The name of the computer being investigated. It can contain only letters, ers, and symbols.
2. Des	cription: An optional one-line description or note about this computer.
local s	te zone: An optional timezone value (i.e. EST5EDT). If not given, it defaults to the etting. A list of time zones can be found in the help files. The eskew Adjustment: An optional value to describe how many seconds this compute
	was out of sync. For example, if the computer was 10 seconds fast, then enter -10 to nsate.
5. Pat	h of Alert Hash Database: An optional hash database of known bad files.
6. Pat	h of Ignore Hash Database: An optional hash database of known good files.



Adding host: host1 to case example1

Host Directory (/var/lib/autopsy/example1/host1/) created

Configuration file (/var/lib/autopsy/example1/host1/host.aut) created

We must now import an image file for this host

ADD IMAGE



Case: example1
Host: host1

No images have been added to this host yet

Select the Add Image File button below to add one

FILE ACTIVITY TIME LINES

VIEW NOTES

ADD IMAGE FILE CLOSE HOST

HELP

IMAGE INTEGRITY HASH DATABASES

EVENT SEQUENCER



Case: example1
Host: host1

ADD A NEW IMAGE

1. Location Enter the full path (starting with /) If the image is split (either raw or E		or the extension.
/home/chris/Downloads/usb.img		
2. Type Please select if this image file is for	a disk or a single partit	tion.
Disk	O Partition	
3. Import Method To analyze the image file, it must be its current location using a symbolic system failure occurs during the mo	c link, by copying it, or	by moving it. Note that if a
Symlink	О Сору	O Move



Warning: Autopsy could not determine the volume system type for the disk image (i.e. the type of partition table). Please select the type from the list below or reclassify the image as a volume image instead of as a disk image.				
Disk Image ○ Volume System Type (disk image only): bsd ✔	Volume Image •			
ОК				




Image File Details

Local Name: images/usb.img	
Data Integrity: An MD5 hash can be used to verify the integrity of the image. (Wimages, this hash is for the full image file)	ith split
 Ignore the hash value for this image. 	
O Calculate the hash value for this image.	
Add the following MD5 hash value for this image:	
☐ Verify hash after importing?	
File System Details	
Analysis of the image file shows the following partitions:	
ADD CANCEL HELP	

For your reference, the mmls output was the following:






Autopsy/FTK imager



- Autopsy is also available on windows
 - This provides a better GUI
- FTK imager is also available for forensic analysis
 - This also has a decent GUI


FTK GUI





00000000 EB 3C 90 4D 53 44 4F 53-35 00000010 02 00 02 00 00 F8 EF 00-3F 00000020 00 B8 3B 00 80 01 29 AE-07 00000030 4D 45 20 20 20 20 46 41-54 00000040 8E D1 BC F0 7B 8E D9 B8-00 00000050 38 4E 24 7D 24 8B C1 99-E8 00000060 66 A1 1C 7C 26 66 3B 07-26

00000070 02 88 56 02 80 C3 10 73-EB



























Proud Sponsors







